






ThinkPad® Important Information about the ThinkPad® Tablet 2 Bluetooth Keyboard with Stand

<http://www.lenovo.com/safety>



Important information about the keyboard

This section provides important information about using the ThinkPad Tablet 2 Bluetooth Keyboard with Stand (hereafter called the keyboard).

Turning on and turning off the keyboard

To turn on the keyboard, slide the power switch **1** to the right side.

To turn off the keyboard, slide the power switch **2** to the right side and hold it for at least three seconds.

About the status LED

The status light-emitting diode (LED) **1** indicates the keyboard status. Refer to the following table for details.

Status LED	Color	Description
Fading in	Green	The keyboard is turned on.
Blinking twice at one second intervals	Green	The keyboard is in pairing mode or is establishing a connection with the ThinkPad Tablet 2 (hereafter called the tablet).
Blinking for five times	Green	The keyboard has established a connection with the tablet.
Fading out	Green	The keyboard is turned off.
Blinking for three times	Amber	The battery power is low.

About the dc-in LED

The dc-in LED **1** indicates the keyboard charging status:

- Blinking in green at three second intervals: The keyboard is on charge.
- Off: The keyboard is fully charged.

Pairing the keyboard with the tablet

To establish a connection and exchange data between the keyboard and the tablet, pair the keyboard with the tablet by doing the following:

Note: You can pair the keyboard to up to three tablets. If you have paired the keyboard with three tablets, the pairing information for the earliest-connected tablet will be deleted whenever you want to pair the keyboard with a new tablet.

- Swipe in from the right edge of the tablet screen to display the charms.
- Tap the **Settings** charm.
- Tap **Change PC settings**.
- In the navigation panel, tap **Devices**.
- Turn on the keyboard.
- Tap **Add a device**.
- Tap **ThinkPad Keyboard**.

Type the eight-digit passcode shown on the tablet screen into the keyboard, and then press Enter. The pairing process begins. After the status LED **1** turns off, the keyboard has been successfully paired with the tablet and established a connection.

Unpairing the keyboard from the tablet

To unpair the keyboard from the tablet, do the following:

- Swipe in from the right edge of the tablet screen to display the charms.
- Tap the **Settings** charm.
- Tap **Change PC settings**.
- In the navigation panel, tap **Devices**.
- Tap **ThinkPad Keyboard**.
- Tap the button on the right side of the area that you selected.
- Tap **Remove** to unpair the keyboard from the tablet.

Establishing a connection between the keyboard and tablet

To exchange data, you must establish a connection between the keyboard and a paired tablet.

To establish a connection between the keyboard and a paired tablet, do the following:

- Turn on the tablet.
- Turn on the keyboard. The status LED **1** will blink in green for five times and then turns off after the keyboard successfully establishes a connection with the paired tablet.

Entering pairing mode

To enter pairing mode when the keyboard has established a connection to a paired tablet, press Fn+Delete. Then, the keyboard disconnects from the paired tablet and enters pairing mode. You can pair the keyboard with a new tablet.

Resetting the keyboard

Attention: All pairing information stored on the keyboard will be deleted after you reset the keyboard to the factory default settings.

To reset the keyboard to the factory default settings, turn off the keyboard first. Then, hold the power switch to the right and press Esc and Delete at the same time. After the status LED **1** blinks in amber and green alternatively and then turns off, the keyboard returns to the factory default settings.

For more information about the keyboard, refer to the user guide that comes with your ThinkPad Tablet 2. The user guide also is available on the Lenovo Support Web site at: <http://www.lenovo.com/support>

Informações importantes sobre o teclado

Esta seção fornece informações importantes sobre o uso do ThinkPad Tablet 2 Bluetooth Keyboard with Stand (daqui em diante chamado de teclado).

Ligando e desligando o teclado

Para ligar o teclado, deslize a chave liga/desliga **1** para a direita.

Para desligar o teclado, deslize a chave liga/desliga **2** para a direita e segure-a por pelo menos três segundos.

Sobre o LED de status

O LED de status **1** indica o status do teclado. Consulte a tabela a seguir para obter detalhes:

LED de status	Cor	Descrição
Aceso	Verde	O teclado está ligado.
Piscando duas vezes em intervalos de um segundo	Verde	O teclado está no modo de pareamento ou estabelecendo conexão com o ThinkPad Tablet 2 (daqui em diante chamado de tablet).
Piscando cinco vezes	Verde	O teclado estabeleceu uma conexão com o tablet.
Apagado	Verde	O teclado está desligado.
Piscando três vezes	Ambar	A carga da bateria está fraca.

Sobre o LED de entrada CC

O LED de entrada CC **1** indica o status de carregamento do teclado:

- Piscando em verde em intervalos de três segundos: O teclado está sendo carregado.
- Apagado: o teclado está totalmente carregado.

Parando o teclado com o tablet

Para estabelecer uma conexão e trocar dados entre o teclado e o tablet, pareie o teclado com o tablet ao fazer o seguinte:

Nota: O teclado se pode ser pareado com até três tablets. Se você pareou o teclado com três tablets, as informações de pareamento do teclado serão excluídas sempre que você desligar o teclado com um novo tablet.

- Deslize a partir da borda direita da tela do tablet para exibir os botões.
- Toque no botão **Configurações**.
- Toque em **Mudar configurações do computador**.
- No painel de navegação, toque em **Dispositivos**.
- Ligue o teclado.
- Toque em **Adicionar um dispositivo**.
- Toque em **Teclado do ThinkPad**.

Digite no teclado a senha com oito dígitos mostrada na tela do tablet e, em seguida, pressione Enter. O processo de pareamento é iniciado. Quando o LED de status **1** apaga, o teclado foi pareado com êxito com o tablet e estabeleceu uma nova conexão.

Cancelando o pareamento do teclado com o tablet

Para cancelar o pareamento do teclado com o tablet, faça o seguinte:

- Deslize a partir da borda direita da tela do tablet para exibir os botões.
- Toque no botão **Configurações**.
- Toque em **Mudar configurações do computador**.
- No painel de navegação, toque em **Dispositivos**.
- Toque em **Teclado do ThinkPad**.
- Toque no botão à direita da área que você selecionou.
- Toque em **Remover** para cancelar o pareamento do teclado com o tablet.

Estabelecendo uma conexão entre o teclado e o tablet

Para trocar dados, você deve estabelecer uma conexão entre o teclado e um tablet pareado.

Para estabelecer uma conexão entre o teclado e um tablet pareado, faça o seguinte:

- Ligue o tablet.
- Ligue o teclado. O LED de status **1** piscará em verde por cinco minutos e, em seguida, apagará após o teclado estabelecer uma conexão com o tablet pareado.

Redefinindo o Teclado

Atenção: Todas as informações de pareamento armazenadas no teclado serão excluídas quando o teclado for redefinido para as configurações padrão de fábrica.

Para restaurar o teclado para as configurações padrão de fábrica, desligue-o primeiro. Em seguida, mantenha o botão liga/desliga à direita e pressione Esc e Delete ao mesmo tempo. Após o LED de status **1** piscar alternadamente em ambar e verde e apagar, o teclado retorna às configurações padrão de fábrica.

Para obter mais informações sobre o teclado, consulte o guia do usuário que acompanha seu ThinkPad Tablet 2. O guia do usuário também está disponível no Web site de suporte da Lenovo em: <http://www.lenovo.com/support>

Důležité informace o klávesnici

Tato část obsahuje důležité informace o používání klávesnice ThinkPad Tablet 2 Bluetooth Keyboard with Stand (dále jen klávesnice).

Zapnutí a vypnutí klávesnice

Klávesnici můžete zapnout, ať jste měli vypnutá. Pokud jste klávesnici spárovali s třemi tablety, informace o spárování s tabletem, který byl připojen jako první, budou vymazány pokročí, když budete chtít spárovat klávesnicí s novým tabletem.

O kontrole LED

Kontrolka LED (light-emitting diode) **1** zobrazení stav klávesnice. Podrobnosti nalezete v následující tabulce.

Kontrolka LED	Barva	Popis
Svítil	Zelená	Klávesnice je zapnutá.
Blikne dvakrát v jednosekundovém intervalu	Zelená	Klávesnice je v režimu párování nebo navazuje spojení se zařízením ThinkPad Tablet 2 (dále jen tablet).
Blikne pětkrát po sobě	Zelená	Klávesnice navázala spojení s tabletem.
Blikne třikrát po sobě	Oranžová	Baterie je vybitá.

O kontrole LED napájení

Kontrolka LED napájení **1** udává stav nabíjení klávesnice:

- Bliká zeleně v třísekundovém intervalu: Klávesnice je připojena k napájení.
- Nesvítil: Klávesnice je plně nabitá.

Párování klávesnice s tabletem

Chcete-li navázat spojení a umožnit výměnu dat mezi klávesnicí a tabletem, spárujte klávesnicí s tabletem takto:

Poznámka: Klávesnici můžete spárovat až s třemi tablety. Pokud jste klávesnici spárovali s třemi tablety, informace o spárování s tabletem, který byl připojen jako první, budou vymazány pokročí, když budete chtít spárovat klávesnicí s novým tabletem.

- Přetáhnutím prstu z pravého okraje tabletu zobrazíte ovládací tlačítka.
- Klepněte na tlačítko **Nastavení**.
- Klepněte na položku **Změnit nastavení počítače**.
- V navigačním panelu klepněte na tlačítko **Zařízení**.
- Zapněte klávesnicí.
- Klepněte na tlačítko **Přidat zařízení**.
- Klepněte na položku **Klávesnice ThinkPad**.
- Zadejte na klávesnici osmičíslné heslo zobrazené na obrazovce tabletu a stiskněte klávesu Enter. Spustí se proces párování. Jakmile zhasne kontrolka LED **1**, je klávesnice úspěšně spárována s tabletem a spojení je navázáno.

Zrušení párování klávesnice s tabletem

Párování klávesnice s tabletem zrušíte takto:

- Přetáhnutím prstu z pravého okraje tabletu zobrazíte ovládací tlačítka.
- Klepněte na tlačítko **Nastavení**.
- Klepněte na položku **Změnit nastavení počítače**.
- V navigačním panelu klepněte na tlačítko **Zařízení**.
- Zapněte klávesnicí.
- Klepněte na položku **Klávesnice ThinkPad**.
- Klepněte na tlačítko v pravé části vybrané oblasti.
- Párování klávesnice s tabletem zrušíte klepnutím na tlačítko **Odstranit**.

Navázání spojení mezi klávesnicí a tabletem

Aby bylo možné vyměňovat data mezi klávesnicí a spárovaným tabletem, musíte mezi těmi dvěma zařízeními navázat spojení.

Spojení mezi klávesnicí a spárovaným tabletem navázáte takto:

- Zapněte tablet.
- Zapněte klávesnicí. Kontrolka LED **1** zeleně blikne pětkrát po sobě a jakmile klávesnice úspěšně naváže spojení se spárovaným tabletem, kontrolka zhasne.

Přepnutí do režimu párování

Chcete-li přepnout do režimu párování, když klávesnice navázala spojení se spárovaným tabletem, stiskněte klávesy Fn+Delete. Klávesnice se odpojí od spárovaného tabletu a přejde do režimu párování. Klávesnici můžete spárovat s novým tabletem.

Resetování klávesnice

Upozornění: Resetováním klávesnice do výchozího stavu z výroby smazáte všechny informace o párování uložené v klávesnici.

Chcete-li resetovat klávesnicí do výchozího stavu z výroby, musíte ji nejprve vypnout. Pole roztáhnutí hlavního okraje tabletu na levé straně klepněte a současně klávesy Esc a Delete. Kontrolka LED **1** začne střídavě blikat oranžově a zeleně a poté zhasne. Klávesnice se vrátí do výchozího stavu z výroby.

Další informace o klávesnici naleznete v uživatelské příručce k ThinkPad Tablet 2. Uživatelská příručka je také dostupná na webové stránce podpory Lenovo na adrese: <http://www.lenovo.com/support>

Informazioni importanti sul tastierino

Questa sezione fornisce informazioni importanti sull'utilizzo di ThinkPad Tablet 2 Bluetooth Keyboard with Stand (d'ora in avanti denominata tastiera).

Accensione e spegnimento della tastiera

Per spegnere la tastiera, far scorrere l'interruttore di alimentazione **1** verso destra.

Per attivare la tastiera, far scorrere l'interruttore di alimentazione **2** verso destra e tenerlo premuto per almeno tre secondi.

Informazioni sul LED di stato

Il LED (Light-Emitting Diode) di stato **1** indica lo stato della tastiera. Per informazioni dettagliate, fare riferimento alla seguente tabella.

LED di stato	Colore	Descrizione
Dissozianza in entrata	Verde	La tastiera è accesa.
Lampeggiamento due volte a intervalli di un secondo	Verde	Il tastierino è in modalità di accoppiamento o sta stabilendo una connessione con ThinkPad Tablet 2 (d'ora in avanti denominato tablet).
Lampeggiamento per cinque volte	Verde	La tastiera ha stabilito una connessione con il tablet.
Dissozianza in uscita	Verde	La tastiera è spenta.
Lampeggiamento per tre volte	Ambr	L'alimentazione della batteria è insufficiente.

Informazioni sul LED di ingresso CC

Il LED di ingresso CC **1** indica lo stato di caricamento della tastiera:

- Lampeggiante verde a intervalli di tre secondi: la tastiera è in carica.
- Spento: la tastiera è completamente carica.

Accoppiamento della tastiera con il tablet

Per stabilire una connessione e scambiare dati tra la tastiera e il tablet, accoppiare la tastiera con il tablet procedendo nel modo seguente:

Nota: è possibile accoppiare la tastiera con un massimo di tre tablet. Se è stata accoppiata la tastiera con tre tablet, le informazioni sull'accoppiamento per il tablet connesso per primo verranno eliminate ogni volta che si desidera accoppiare la tastiera con un nuovo tablet.

- Scorrere un dito verso l'interno dal bordo destro dello schermo del tablet per visualizzare la icone promemoria.
- Toccare l'icona promemoria **Impostazioni**.
- Nel pannello di navigazione, toccare **Dispositivi**.
- Toccare **Aggiungi un dispositivo**.
- Toccare **Tastiera ThinkPad**.
- Digitare sulla tastiera il passcode a otto cifre mostrato sullo schermo del tablet, quindi premere Invio. Viene avviato il processo di accoppiamento. Dopo che il LED di stato **1** si è spento, la tastiera è stata correttamente accoppiata con il tablet e ha stabilito una connessione.

Procedura per stabilire una connessione tra la tastiera e il tablet

Per scambiare i dati, è necessario stabilire una connessione tra la tastiera e un tablet accoppiato.

Per stabilire una connessione tra la tastiera e un tablet accoppiato, procedere nel modo seguente:

- Accendere il tablet.
- Accendere la tastiera. Il LED di stato **1** lampeggerà di verde per cinque volte e si sposterà dopo che la tastiera ha stabilito correttamente una connessione con il tablet accoppiato.

Attivazione della modalità di accoppiamento

Per attivare la modalità di accoppiamento quando la tastiera ha stabilito una connessione con un tablet accoppiato, premere Fn+Canc. La tastiera viene quindi disconnessa dal tablet accoppiato e viene attivata la modalità di accoppiamento. È possibile accoppiare la tastiera con un nuovo tablet.

Reimpostazione della tastiera

Attenzione: tutte le informazioni sull'accoppiamento memorizzate nella tastiera verranno eliminate dopo avere ripristinato le impostazioni predefinite originali della tastiera.

Per ripristinare le impostazioni predefinite originali della tastiera, spegnere prima la tastiera. Far scorrere quindi l'interruttore di alimentazione verso destra e tenere premuto contemporaneamente Esc e Canc. Dopo che il LED di stato **1** ha lampeggiato alternativamente di giallo e verde e si è spento, vengono ripristinate le impostazioni predefinite originali della tastiera.

Per ulteriori informazioni sulla tastiera, fare riferimento alla guida per l'utente fornita con ThinkPad Tablet 2. La guida per l'utente è disponibile anche sul sito Web di supporto Lenovo all'indirizzo: <http://www.lenovo.com/support>

Wichtige Informationen zur Tastatur

Dieser Abschnitt bietet wichtige Informationen zur Benutzung des ThinkPad Tablet 2 Bluetooth Keyboard with Stand (im Folgenden als Tastatur bezeichnet).

Ein- und Ausschalten der Tastatur

Schieben Sie zum Einschalten der Tastatur den Betriebsspannungsschalter **1** nach rechts.

Schieben Sie zum Ausschalten der Tastatur den Betriebsspannungsschalter **2** nach rechts und halten Sie ihn für mindestens drei Sekunden gedrückt.

Informationen zur Statusanzeige-LED

Die Statusanzeige-LED **1** gibt den Status der Tastatur an. Ausführliche Informationen hierzu erhalten Sie in der folgenden Tabelle.

Statusanzeige-LED	Farbe	Beschreibung
Geht langsam an	Grün	Die Tastatur wird eingeschaltet.
Blinkt zweimal mit einer Unterbrechung von einer Sekunde	Grün	Die Tastatur ist im Pairing-Modus oder baut eine Verbindung zum ThinkPad Tablet 2 auf (im Folgenden als Tablet bezeichnet).
Blinkt fünfmal	Grün	Die Tastatur hat eine Verbindung zum Tablet aufgebaut.
Geht langsam aus	Grün	Die Tastatur wird ausgeschaltet.
Blinkt dreimal	Gelb	Die Akkuleistung ist niedrig.

Informationen zur Netzeingangs-LED

Die Netzeingangs-LED **1** zeigt den Tastaturzustand an:

- LED blinkt alle drei Sekunden grün: Die Tastatur wird aufgeladen.
- Aus: Die Tastatur ist aufgeladen.

Pairing von Tastatur und Tablet

Führen Sie ein Pairing mit der Tastatur und dem Tablet zum Verbindungsaufbau und Datenaustausch zwischen der Tastatur und dem Tablet folgendermaßen aus:

Hinweis: Sie können ein Pairing zwischen der Tastatur und bis zu drei Tablets ausführen. Wenn Sie ein Pairing der Tastatur mit drei Tablets ausgeführt haben, werden die Pairing-Informationen für das zuerst verbundene Tablet gelöscht, sobald Sie ein Pairing der Tastatur mit einem neuen Tablet aufbauen.

- Gleiten Sie vom rechten Rand aus auf den Tablet-Bildschirm, um die Charm-Leiste anzuzeigen.
- Tippen Sie auf die Charm-Leiste **Einstellungen**.
- Tippen Sie auf **PC-Einstellungen ändern**.
- Tippen Sie in der Navigationsanzeige auf **Geräte**.
- Schalten Sie die Tastatur ein.
- Tippen Sie auf **Gerät hinzufügen**.
- Tippen Sie auf **ThinkPad-Tastatur**.
- Tippen Sie den achtstelligen Passcode, der auf dem Tablet-Bildschirm angezeigt wird, mit der Tastatur ein und drücken Sie die Eingabetaste. Der Pairing-Vorgang wird gestartet. Wenn die Statusanzeige-LED **1** erlischt ist, war das Pairing der Tastatur mit dem Tablet erfolgreich und eine Verbindung wurde aufgebaut.

Aufheben des Pairings von Tastatur und Tablet

So heben Sie das Pairing der Tastatur und dem Tablet auf:

- Gleiten Sie vom rechten Rand aus auf den Tablet-Bildschirm, um die Charm-Leiste anzuzeigen.
- Tippen Sie auf die Charm-Leiste **Einstellungen**.

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

##

Telephone technical support

Information is available through the Customer Support Center which will be available until 90 days after the option has been withdrawn from marketing. After that time, the support is cancelled, or made available for a fee, at Lenovo's discretion.

Support is also available in other languages at www.lenovo.com/support. Before contacting a Lenovo technical support representative, please have the following information available: model number, date of purchase, computer manufacturer, model, serial number and manual, the exact wording of any error message, description of the problem, and the hardware and software configuration information for your computer.

Your technical support representative might want to walk you through the problem while you are at your computer. If you are unable to do so, you may be able to schedule a telephone reseller or Lenovo marketing representative.

Lenovo Limited Warranty

L505-0010-02 08/2011
This Lenovo Limited Warranty consists of the following parts:
Part 1 - General Terms
Part 2 - Country-specific Terms
Part 3 - Warranty Service Information

The terms of **Part 2** replace or modify terms of **Part 1** as specified for a particular country.
Part 1 - General Terms
This Lenovo Limited Warranty applies only to Lenovo hardware products you purchased for your own use and not for resale.
This Lenovo Limited Warranty is available in other languages at www.lenovo.com/warranty.
What This Warranty Covers
Lenovo warrants that each Lenovo hardware product that you purchase is free from defects in materials and workmanship under normal use and conditions during the warranty period. The warranty period for the product starts on the original date of purchase as shown on your sales receipt or invoice or as may be otherwise specified by Lenovo. The warranty period and type of warranty service that apply to your product are as specified in "**Part 3 - Warranty Service Information**" below. This warranty only applies to products shipped from Lenovo.
THIS WARRANTY IS YOUR EXCLUSIVE WARRANTY AND REPLACES ALL OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR USE. AS SOME STATES OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF EXPRESS OR IMPLIED WARRANTIES, THIS EXCLUSION MAY APPLY TO YOU. IN THAT EVENT, SUCH WARRANTIES APPLY ONLY TO THE EXTENT AND FOR SUCH DURATION AS REQUIRED BY LAW AND ARE LIMITED IN DURATION TO THE MAXIMUM PERIOD ALLOWED BY APPLICABLE LAW. ALLOW LIMITATIONS ON THE DURATION OF AN IMPLIED WARRANTY, THE ABOVE LIMITATION ON DURATION MAY NOT APPLY TO YOU.
How to Obtain Warranty Service
If the product does not function as warranted during the warranty period, you may obtain warranty service by contacting Lenovo or a Lenovo approved Service Provider. A list of approved Service Providers and their telephone numbers is available at www.lenovo.com/support.
Warranty service may not be available in all locations and may differ from location to location. Charges may apply outside a Service Provider's normal service area.
Customer Responsibilities for Warranty Service
Before warranty service is provided, you must take the following steps:

- follow the service request procedures specified by the Service Provider
- backup or secure all programs and data contained in the product
- provide the Service Provider with all system keys or passwords
- provide the Service Provider with sufficient, free, and safe access to your facilities to perform service
- remove all data, including confidential information, proprietary information and personal information, from the product or, if you are unable to remove any such information, notify the Service Provider of such information so that it is not personal data under applicable law. The Service Provider shall not be responsible for the loss or disclosure of any data, including confidential information, proprietary information, or personal information, on a product returned or accessed for warranty service
- remove all features, parts, options, alterations, and attachments not covered by the warranty
- ensure that the product or part is free of any legal restrictions that prevent its replacement
- if you are not the owner of a product or part, obtain authorization from the owner of the Service Provider before you return the product to the Service Provider.

What Your Service Provider Will Do to Correct Problems
When you contact a Service Provider, you must provide the specified problem determination and resolution procedures.
The Service Provider will attempt to diagnose and resolve your problem by telephone, email or remote assistance. The Service Provider may direct you to download and install designated software updates.
Some problems may be resolved with a replacement part that you install yourself. Call your Customer Representative for details on "CRU." If so, the Service Provider will ship the CRU to you for you to install.
If your problem cannot be resolved over the telephone, through the application of software updates or the installation of a CRU, the Service Provider will arrange for service under the type of warranty specified for the product under "**Part 3 - Warranty Service Information**" below.
If the Service Provider determines that it is unable to repair your product, the Service Provider may offer you a replacement product or part.
If the Service Provider determines that it is unable to either repair or replace your product, your sole remedy under this Limited Warranty is to return the product to your purchase or return to Lenovo for a refund of your purchase price.
Replacement Products and Parts
When warranty service involves the replacement of a product or part, the replaced product or part becomes Lenovo's property and the replacement product or part is the property of the customer. Only under the terms of the warranty may the replaced product or part be returned to the customer. The replacement product or part provided by Lenovo may not be new, but it will be in good working order and at least functionally equivalent to the original product or part. The replacement product or part shall be warranted for the balance of the period remaining on the original product.
Use of Personal Contact Information
If you obtain service under this warranty, you authorize Lenovo to store, use and disclose information about your warranty and contact information, including name, phone numbers, address, and e-mail address. Lenovo may use this information to perform service. We may contact you by telephone or email to discuss your satisfaction with our warranty service or to notify you about any product recalls or safety issues. In accomplishing these purposes, you authorize Lenovo to transfer your information to any third party to do business and to provide it to entities acting on our behalf. We may also disclose it where required by law. Lenovo's privacy policy is available at www.lenovo.com/privacy.
What This Warranty Does Not Cover
This warranty does not cover the following:

- unintended or error-free operation of a product
- loss of, or damage to, your data by a product
- any software programs, whether provided with the product or installed independently
- failure or damage resulting from misuse, abuse, accident, modification, unstable physical or operating environment, natural disasters, power surges, improper maintenance, or use not in accordance with product information materials
- damage caused by a non-authorized service provider
- failure of, or damage caused by, any third party products, including those that Lenovo may provide or integrate into the Lenovo product at your request
- any technical or other support, such as assistance with "how-to" questions and questions regarding product set-up or installation
- products or parts with an altered identification label or from which the identification label has been removed

Limitation of Liability
Lenovo is responsible for loss or damage to your product only while it is in the Service Provider's possession or in transit, if the Service Provider is responsible for the transportation.
Neither Lenovo nor the Service Provider is responsible for loss or disclosure of any data, including confidential information, proprietary information, or personal information, contained in a product.
NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE FAILURE OF ESSENTIAL PURPOSE OF ANY REMEDY SET FORTH HEREIN, SHALL LENOVO, ITS AFFILIATES, SUPPLIERS, RESELLERS, OR SERVICE PROVIDERS BE LIABLE FOR ANY OF THE FOLLOWING, EVEN IF INFORMED OF THEIR POSSIBILITY AND REGARDLESS OF WHETHER THE CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE, STRICT LIABILITY OR OTHER THEORY OF LIABILITY. (1) THIRD PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS, DAMAGE OR DISCLOSURE OF YOUR DATA; (3) SPECIAL, INCIDENTAL, PUNITIVE, INDIRECT OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOST PROFITS, BUSINESS REVENUE, GOODWILL OR ANTICIPATED SAVINGS. IN NO CASE SHALL THE TOTAL LIABILITY OF LENOVO, ITS AFFILIATES, SUPPLIERS, RESELLERS OR SERVICE PROVIDERS FOR DAMAGES FROM ANY CAUSE EXCEED THE AMOUNT OF ACTUAL DIRECT DAMAGES, NOT TO EXCEED THE AMOUNT PAID FOR THE PRODUCT.
THE FOREGOING LIMITATIONS DO NOT APPLY TO DAMAGES FOR BODILY INJURY (INCLUDING DEATH), DAMAGE TO REAL PROPERTY OR DAMAGE TO TANGIBLE PERSONAL PROPERTY FOR WHICH LENOVO IS LIABLE UNDER LAW.
AS SOME STATES OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL DAMAGES, THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.
Your Other Rights
THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHER RIGHTS ACCORDING TO THE APPLICABLE LAWS OF YOUR STATE OR JURISDICTION. YOU MAY ALSO HAVE OTHER RIGHTS UNDER A WRITTEN AGREEMENT WITH LENOVO. NOTHING IN THIS WARRANTY AFFECTS STATUTORY RIGHTS, INCLUDING RIGHTS OF CONSUMERS UNDER LAWS OR REGULATIONS GOVERNING THE SALE OF CONSUMER GOODS THAT CANNOT BE WAIVED OR LIMITED BY CONTRACT.
Part 2 - Country-specific Terms

Australia

"Lenovo" means Lenovo (Australia & New Zealand) Pty Limited ABN 70 112 394 411. Address: Level 10, North Tower, 1-5 Railway Street, Chatswood, NSW, 2067. Telephone: +61 2 8003 2820. Email: lenasyd_a@lenovo.com

The following replaces the same section in Part 1:

What This Warranty Covers
This warranty warrants that each hardware product that you purchase is free from defects in materials and workmanship under normal use and conditions during the warranty period. If the product fails due to a covered defect during the warranty period, Lenovo will provide you a remedy under the Limited Warranty. The warranty period for the product starts on the original date of purchase specified on your sales receipt or invoice unless Lenovo informs you otherwise in writing. The warranty period and type of warranty service that apply to your product are set forth below in **Part 3 - Warranty Service Information**.

THE BENEFITS GIVEN BY THIS WARRANTY ARE IN ADDITION TO YOUR RIGHTS AND REMEDIES AT LAW, INCLUDING THOSE UNDER THE AUSTRALIAN CONSUMER LAW.

The following replaces the same section in Part 1:

Replacement Products and Parts:
When warranty service involves the replacement of a product or part, the replaced product or part becomes Lenovo's property and the replacement product or part is the property of the customer. Only under the terms of the warranty may the replaced product or part be returned to the customer. The replacement product or part provided by Lenovo may not be new, but it will be in good working order and at least functionally equivalent to the original product or part. The replacement product or part shall be warranted for the balance of the period remaining on the original product.

Use of Personal Contact Information:
If you obtain service under this warranty, you authorize Lenovo to store, use and disclose your information to perform service. We may contact you by telephone or email to discuss your satisfaction with our warranty service or to notify you about any product recalls or safety issues. In accomplishing these purposes, you authorize Lenovo to transfer your information to any third party to do business and to provide it to entities acting on our behalf. We may also disclose it where required by law. Lenovo's privacy policy is available at www.lenovo.com/privacy.

What This Warranty Does Not Cover:
This warranty does not cover the following:

• unintended or error-free operation of a product
• loss of, or damage to, your data by a product
• any software programs, whether provided with the product or installed independently
• failure or damage resulting from misuse, abuse, accident, modification, unstable physical or operating environment, natural disasters, power surges, improper maintenance, or use not in accordance with product information materials
• damage caused by a non-authorized service provider
• failure of, or damage caused by, any third party products, including those that Lenovo may provide or integrate into the Lenovo product at your request
• any technical or other support, such as assistance with "how-to" questions and questions regarding product set-up or installation
• products or parts with an altered identification label or from which the identification label has been removed

Limitation of Liability:
Lenovo is responsible for loss or damage to your product only while it is in the Service Provider's possession or in transit, if the Service Provider is responsible for the transportation.

Neither Lenovo nor the Service Provider is responsible for loss or disclosure of any data, including confidential information, proprietary information, or personal information, contained in a product.

NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE FAILURE OF ESSENTIAL PURPOSE OF ANY REMEDY SET FORTH HEREIN, SHALL LENOVO, ITS AFFILIATES, SUPPLIERS, RESELLERS, OR SERVICE PROVIDERS BE LIABLE FOR ANY OF THE FOLLOWING, EVEN IF INFORMED OF THEIR POSSIBILITY AND REGARDLESS OF WHETHER THE CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE, STRICT LIABILITY OR OTHER THEORY OF LIABILITY. (1) THIRD PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS, DAMAGE OR DISCLOSURE OF YOUR DATA; (3) SPECIAL, INCIDENTAL, PUNITIVE, INDIRECT OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOST PROFITS, BUSINESS REVENUE, GOODWILL OR ANTICIPATED SAVINGS. IN NO CASE SHALL THE TOTAL LIABILITY OF LENOVO, ITS AFFILIATES, SUPPLIERS, RESELLERS OR SERVICE PROVIDERS FOR DAMAGES FROM ANY CAUSE EXCEED THE AMOUNT OF ACTUAL DIRECT DAMAGES, NOT TO EXCEED THE AMOUNT PAID FOR THE PRODUCT.

THE FOREGOING LIMITATIONS DO NOT APPLY TO DAMAGES FOR BODILY INJURY (INCLUDING DEATH), DAMAGE TO REAL PROPERTY OR DAMAGE TO TANGIBLE PERSONAL PROPERTY FOR WHICH LENOVO IS LIABLE UNDER LAW.

AS SOME STATES OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL DAMAGES, THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

Your Other Rights
THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU ALSO HAVE OTHER RIGHTS AT LAW, INCLUDING UNDER THE AUSTRALIAN CONSUMER LAW.

NOTHING IN THIS WARRANTY AFFECTS STATUTORY RIGHTS OR RIGHTS AT LAW, INCLUDING RIGHTS THAT CANNOT BE WAIVED OR LIMITED BY CONTRACT.

For example, our products come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the products repaired or replaced if the products fail to be of acceptable quality and the failure does not amount to a major failure.

New Zealand

The following is added to the same section in Part 1:

Use of Personal Information:
Lenovo will not be able to perform our service under this warranty if you refuse to provide your information or do not wish us to transfer your information to our agent or contractor. You have the right to access your personal contact information and request correction of any errors in it pursuant to the Privacy Act 1988 by contacting Lenovo@lenovo.com.

Limitation of Liability:
Lenovo is responsible for loss or damage to your product only while it is in the Service Provider's possession or in transit, if the Service Provider is responsible for the transportation.

Neither Lenovo nor the Service Provider is responsible for loss or disclosure of any data, including confidential information, proprietary information, or personal information, contained in a product.

TO THE EXTENT PERMITTED BY LAW, UNDER NO CIRCUMSTANCES AND REGARDLESS OF WHETHER THE FAILURE OF ESSENTIAL PURPOSE OF ANY REMEDY SET FORTH HEREIN, SHALL LENOVO, ITS AFFILIATES, SUPPLIERS, RESELLERS, OR SERVICE PROVIDERS BE LIABLE FOR ANY OF THE FOLLOWING, EVEN IF INFORMED OF THEIR POSSIBILITY AND REGARDLESS OF WHETHER THE CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE, STRICT LIABILITY OR OTHER THEORY OF LIABILITY. (1) THIRD PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS, DAMAGE OR DISCLOSURE OF YOUR DATA; (3) SPECIAL, INCIDENTAL, PUNITIVE, INDIRECT OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOST PROFITS, BUSINESS REVENUE, GOODWILL OR ANTICIPATED SAVINGS. IN NO CASE SHALL THE TOTAL LIABILITY OF LENOVO, ITS AFFILIATES, SUPPLIERS, RESELLERS OR SERVICE PROVIDERS FOR DAMAGES FROM ANY CAUSE EXCEED THE AMOUNT OF ACTUAL DIRECT DAMAGES, NOT TO EXCEED THE AMOUNT PAID FOR THE PRODUCT.

THE FOREGOING LIMITATIONS DO NOT APPLY TO DAMAGES FOR BODILY INJURY (INCLUDING DEATH), DAMAGE TO REAL PROPERTY OR DAMAGE TO TANGIBLE PERSONAL PROPERTY FOR WHICH LENOVO IS LIABLE UNDER LAW.

AS SOME STATES OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL DAMAGES, THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

Your Other Rights
THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU ALSO HAVE OTHER RIGHTS AT LAW, INCLUDING UNDER THE AUSTRALIAN CONSUMER LAW.

NOTHING IN THIS WARRANTY AFFECTS STATUTORY RIGHTS OR RIGHTS AT LAW, INCLUDING RIGHTS THAT CANNOT BE WAIVED OR LIMITED BY CONTRACT.

For example, our products come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the products repaired or replaced if the products fail to be of acceptable quality and the failure does not amount to a major failure.

European Economic Area (EEA)

The following is added to Part 1:

Customers in the EEA may contact Lenovo at the following address: EMEA Service Organisation, Lenovo (International) B.V., Floor 2, Einsteinstraat 21, 851 01, Bratislava, Slovakia. Service under this warranty for Lenovo hardware products purchased in EEA countries may be obtained in any EEA country in which the product has been announced and made available by Lenovo.

Russia

The following is added to Part 1:

Product Service Life

The product service life is four (4) years from the original date of purchase.

Part 3 - Warranty Service Information

Product Type	Country or Region of Purchase	Warranty Period	Type of Warranty Service
ThinkPad Tablet 2 Bluetooth Keyboard with Stand	Worldwide	1 year	1, 4

If required, the Service Provider will repair or exchange service depending on the type of warranty service specified for your product and the available service. Scheduling of warranty service is dependent on the product and the type of warranty service and other factors.

Types of Warranty Service

1. Customer Replaceable Unit ("CRU") Service
Under CRU Service, the Service Provider will ship CRUs to you at its cost for installation by you. CRU information and replacement instructions are shipped with your product and are available from Lenovo at any time upon request. CRUs that are easily identifiable as such are referred to as "Standard" CRUs. "Optional-service CRUs" are CRUs that may require some technical skill and tools. Installation of Self-Service CRUs is your responsibility. You may request that a Service Provider perform an Optional-service CRU under one of the other types of warranty service designated for your product. An optional service offering may be available for purchase from a Service Provider or retailer, which offers a replacement CRU and the product to be replaced. You may find a list of CRUs and their designation in the publication that was shipped with your product or at www.lenovo.com/CRUs. The requirement to return a defective CRU, if any, will be specified with a replacement CRU. When return is required: (1) return instructions, a prepaid return shipping label, and a return receipt included with the replacement CRU; and (2) you may be charged for the replacement CRU if the Service Provider does not receive the defective CRU within thirty (30) days of your receipt of the replacement CRU.

2. On-site Service

Under On-Site Service, a Service Provider will either repair or exchange the product at your location. You must provide a suitable working area to allow disassembly and reassembly of the product. Some repairs may not be completed at a service center. If so, the Service Provider will return the product to the service center at its expense.

3. Courier or Depot Service

Under Courier or Depot Service, your product will be repaired or exchanged at a designated service center, with shipping at the expense of the Service Provider. You are responsible for disconnecting the product and packing it in a shipping container provided to you to return your product to the designated service center. The service center will return the product to you at its expense.

4. Customer Carry-in Service
Under Customer Carry-in Service, your product will be repaired or exchanged after you deliver it to a designated service center at your risk and expense. After the product has been repaired or exchanged, it will be made available to you for collection. If you fail to collect the product, the Service Provider may dispose of the product as it sees fit, with no liability to you.

5. Mail-In Service

Under Mail-In Service, your product will be repaired or exchanged at a designated service center after you deliver it at its risk and expense. After the product has been repaired or exchanged, it will be returned to you at Lenovo's risk and expense, unless the product is returned to you by the Service Provider.

6. Customer Two-Way Mail-In Service
Under Customer Two-Way Mail-In Service, your product will be repaired or exchanged after you deliver it to a designated service center at your risk and expense. After the product has been repaired or exchanged, it will be made available to you for return shipping at your risk and expense. If you fail to arrange return shipment, the Service Provider may dispose of the product as it sees fit, with no liability to you.

7. Product Exchange Service

Under Product Exchange Service, Lenovo will ship a replacement product to your location. You are responsible for its installation and verification of its operation. The replacement product becomes your property in exchange for the failed product, which becomes the property of Lenovo. You must pack the failed product in the shipping carton in which you received the replacement product and return it to Lenovo.

Transportation charges, both ways, shall be at Lenovo's risk and expense. If you fail to use the carton in which the product was shipped, or if you do not follow the instructions for any damage to the failed product occurring during shipment, You may be charged for the replacement product. If you do not return the failed product within thirty (30) days of your receipt of the replacement product.

Suplemento de Garantía para México
Este Suplemento se considera parte integrante de la Garantía Limitada de Lenovo y será efectivo única y exclusivamente para los productos distribuidos y comercializados dentro del Territorio Mexicano. En caso de conflicto, se aplicarán los términos de este Suplemento.

Todos los programas de software preinstalados en el equipo solo tendrán una garantía limitada de un (1) año a partir de la fecha de instalación desde la fecha de compra. Lenovo no es responsable de la información incluida en dichos programas de software u cualquier programa de software adicional instalado por Usted o instalado después de la compra del producto.
Los servicios no cubiertos por la garantía se cargarán al usuario final, previa obtención de una autorización.
En el caso de que se precise una reparación cubierta por la garantía, por favor, llame al Centro de soporte al cliente al 001-866-434-2080, donde le dirigiran al Centro de servicio autorizado más cercano. Si no existe ningún Centro de servicio autorizado en su ciudad, población o en un radio de 70 kilómetros de su ciudad o población, la garantía incluirá cualquier cargo de envío razonable relacionado con el transporte del producto a su Centro de servicio autorizado más cercano. Por favor, llame al Centro de servicio autorizado más cercano para obtener las aprobaciones necesarias o la información relacionada con el envío del producto y la dirección de envío.
Para obtener una lista de los Centros de servicio autorizados, por favor, visite: <http://www.lenovo.com/mexico>.

Importado por:
Lenovo México S. de R.L. de C.V.
Santa Fe 505, Piso 15
C.O. Cruz Manca
Cajalmita, D.F., México
C. P. 06500
Tel. (55) 5000 8500

Lenovo Limited Warranty - Customer Notice

Lenovo Limited Warranty - Customer Notice
Read the [Lenovo Limited Warranty \(LLW\)](http://www.lenovo.com/warranty/llw_02) at http://www.lenovo.com/warranty/llw_02. If you cannot view the LLW, contact your local Lenovo office or reseller to obtain a printed version of the LLW.

Warranty information available to you at machine:

1. Warranty Period: 1 year
2. Type of Warranty Service: Customer Replaceable Unit (CRU) and Customer Carry-In

3. Lenovo Limited Warranty Version: L505-0010-02 08/2011
For warranty service, consult the telephone number of the Lenovo office or reseller. Phone numbers are subject to change without notice.

Garantía Limitada de Lenovo - Aviso ao Cliente
Leia a [Garantia Limitada de Lenovo \(LLW\)](http://www.lenovo.com/warranty/llw_02) em http://www.lenovo.com/warranty/llw_02. Caso não seja possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:
1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:

1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:

1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:

1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:

1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:

1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:

1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:

1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:

1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:

1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:

1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:

1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:

1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:

1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.

Informações de garantia aplicáveis à sua máquina:

1. Período de Garantia: 1 ano
2. Tipo de Serviço de Garantia: Unidade Substituível pelo Cliente (CRU) e Serviço de Transporte pelo Cliente

3. Versão da Garantia Limitada de Lenovo: L505-0010-02 08/2011
Para obter informações sobre o serviço de garantia, consulte a lista de telefones em http://www.lenovo.com/warranty/llw_02. Se não é possível visualizar a LLW, contate o representante local Lenovo ou distribuidor Lenovo local para obter uma versão impressa da LLW.